

PRODUCT LIST

Picture	Name	FONHO No	Reference No.	Appilcation
	Oil Water Separator	HS-07010	S3208T	Racor
	Oil Water Separator	HS-07011	S3208T	Racor
	Oil Water Separator	HS-08007	R12P	Racor
	Oil Water Separator	HS-08008	R12T	Racor
	Oil Water Separator	HS-09008	S3213	Racor
	Oil Water Separator	HS-10001	R90T, P.N.2914807100	Racor
	Oil Water Separator	HS-10002	R90P, P.N. 2914807000	Racor
	Oil Water Separator	HS-10006	R120T	Racor








PRODUCT LIST

Picture	Name	FONHO No	Reference No.	Appilcation
	Oil Water Separator	HS-10007	R60T	Racor
	Oil Water Separator	HS-10008	33232	Racor
	Oil Water Separator	HS-10015	A0004771302	Racor
	Oil Water Separator	HS-10016	R20T	Racor
	Oil Water Separator	HS-10017	R25T	Racor
	Oil Water Separator	HS-10018	R60P	Racor
	Oil Water Separator	HS-10019	R120P	Racor

PRODUCT LIST

Picture	Name	FONHO No	Reference No.	Appilcation
	Oil Water Separator Assembly	HM-140P	140-1	Racor
	Oil Water Separator Assembly	HM-140T	140-2	Racor
	Oil Water Separator Assembly	HM-230P	230-1	Racor
	Oil Water Separator Assembly	HM-230T	230-2	Racor
	Oil Water Separator Assembly	HM-4120P	4120-1	Racor
	Oil Water Separator Assembly	HM-4120T	4120-2	Racor
	Oil Water Separator Assembly	HM-4120P-S	41200301	Racor

PRODUCT LIST

Picture	Name	FONHO No	Reference No.	Appilcation
	Oil Water Separator Assembly	HM-4120T-S	41200302	Racor
	Oil Water Separator Assembly	HM-460P	460-1	Racor
	Oil Water Separator Assembly	HM-460T	460-2	Racor
	Oil Water Separator Assembly	HM-460P-S	460-3	Racor
	Oil Water Separator Assembly	HM-460T-S	460-4	Racor
	Oil Water Separator Assembly	HM-490P	490-1	Racor
	Oil Water Separator Assembly	HM-490T	490-2	Racor

PRODUCT LIST

Picture	Name	FONHO No	Reference No.	Appilcation
	Oil Water Separator Assembly	HM-6120P	ISUZU 6120-7	Racor
	Oil Water Separator Assembly	HM-6120T	6120-4	Racor
	Oil Water Separator Assembly	HM-660P	660-3	Racor
	Oil Water Separator Assembly	HM-660T	660-4	Racor
	Oil Water Separator Assembly	HM-690P	690-3	Racor
	Oil Water Separator Assembly	HM-690T	690-4	Racor
	Oil Water Separator Assembly	HM-90MER	R90-MER-01	Racor



Full Of Harmony

Ruian FONHO Automotive Co.,Ltd

Add: Luofeng Industrial Park, Tangxia Town, Ruian, China 325204

Tel:+86 577 66070661 Fax:+86 577 66070662 Http://www.fohfilters.com E-mail:info@fohfilters.com

PRODUCT LIST

Picture	Name	FONHO No	Reference No.	Appilcation
	Oil Water Separator Assembly	M-90MER-S	R90-MER-0/D	Racor
	Oil Water Separator Assembly	HM-1080	448023-1080	Racor
	Oil Water Separator Assembly	HM-1412	ME091412	Racor
	Oil Water Separator Assembly	HM-215		Racor
	Oil Water Separator Assembly	HM-141BFS	141BFS	Racor
	Oil Water Separator Assembly	HM-141FS	141FS	Racor
	Oil Water Separator Assembly	HM-9811	ME039811	Racor

PRODUCT LIST

Picture	Name	FONHO No	Reference No.	Appilcation
	Oil Water Separator Assembly	HM-296	7111-296	Racor
	Oil Water Separator Assembly	HM-500FG	500FG	Racor
	Oil Water Separator Assembly	HM-1000FH	1000FH	Racor
	Oil Water Separator Assembly	HM-3640	40853-1/00, 1393640	Racor
	Oil Water Separator Assembly	HM-9751	8159975-1	Racor